


Measurements

SALZBURG R / SALZBURG R +1/ SALZBURG R EXTENSION BASE

 Nordpeis

FIG 1

SALZBURG R = MM / AIR / CHIMNEY




Measurements

SALZBURG R / SALZBURG R +1/ SALZBURG R EXTENSION BASE

 Nordpeis

FIG 2

SALZBURG R EXTENSION BASE = MM / AIR / CHIMNEY



Measurements

SALZBURG R / SALZBURG R +1/ SALZBURG R EXTENSION BASE

Nordpeis

FIG 3

SALZBURG R+1 = MM / AIR / CHIMNEY

