

# Broil King®

---

---



**Broil King.**





REGAL 690  
9972-82  
9972-83




**Broil King.**

REGAL S 690 PRO  
9973-42  
9973-43


**HARDWARE INCLUDED / MATERIAL INCLUS / EQUIPOS INCLUIDO**


Y-12865		(32)	Y-11793		(8)
Y-29304		(2)	 #3 ROBERTSON #2 ROBERTSON		

**TOOLS REQUIRED / OUTILS NECESSAIRES / HERRAMIENTAS NECESARIAS**





# 1

(2) 





# 2



(24) 






3






4



5










6










7

(1)




8







10




# 11



(2)  (2)




# 12



# 13



# 14



**PARTS LIST / LISTE DES PIECES**

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>9972-82</u>	<u>9972-83</u>	<u>9973-42</u>	<u>9973-43</u>
1	27005-004	FIRE BOX ASSEMBLY	1	1	1	1
1A	27003-004	FIRE BOX ASSEMBLY	1	1	1	1
2	86005-301	LID ASSEMBLY - BLACK	1	1	•	•
	86005-304	LID ASSEMBLY - S.S	•	•	1	1
2A	86003-301	LID ASSEMBLY - BLACK	1	1	•	•
	86003-304	LID ASSEMBLY - S.S	•	•	1	1
5	27249-904	GREASE SHIELD	6	6	6	6
7	Y-11544	BURNER SCREW	6	6	6	6
8	S21242	BURNER CLIP	6	6	6	6
18	22022-284	STAINLESS STEEL WIRE	•	•	2	2
	22005-281	CAST IRON GRID	4	4	•	•
18A	22005-281	CAST IRON GRID	2	2	2	2
20	22005-991	GRID - WARMING RACK	1	1	1	1
20A	22003-991	GRID - WARMING RACK	1	1	1	1
22	22025-904	COLLECTOR BOX	1	1	1	1
22A	22023-904	COLLECTOR BOX	1	1	1	1
25	22909-104D	BURNER	6	•	6	•
	22909-104E	BURNER	•	6	•	6
26	22001-769	CONTROL KNOB	6	6	6	6
26A	22001-669	CONTROL KNOB	2	2	2	2
27	22002-264	CONTROL BEZEL	6	6	6	6
27A	22001-164	CONTROL BEZEL	2	2	2	2
28	22008-884	CONTROL COVER	1	1	1	1
32	10111-15A	PIG TAIL HOSE ASSEMBLY	1	1	1	1
34	S13473-073	HOSE-SIDE BURNER	1	•	1	•
	S13473-079	HOSE-SIDE BURNER	•	1	•	1
34A	Y-11230	COTTER PIN	1	1	1	1
35	29018-072	CONTROL ASSEMBLY	1	•	1	•
	29018-075	CONTROL ASSEMBLY	•	1	•	1
36	10342-T21	ELECTRODE – SIDE BURNER	1	1	1	1
37	20809-957	REAR BURNER GAS TRAIN	1	1	1	1
38	Y-11990	HEX NUT	1	1	1	1
43	10342-E13	ELECTRODE	2	2	2	2
43A	10342-E22	ELECTRODE	1	1	1	1
44	10342-45	ELECTRONIC IGNITOR	1	1	1	1
44A	25070-92	IGNITOR WIRE	1	1	1	1
44B	25070-93	IGNITOR BUTTON	1	1	1	1
47	21035-991	GREASE RAIL	2	2	2	2
47A	21033-991	GREASE RAIL	2	2	2	2
48	22009-901	GREASE PAN	2	2	2	2
49	27055-901	GREASE TRAY	1	1	1	1
49A	27053-901	GREASE TRAY	1	1	1	1
51	22209-904	FLAV-R-WAVE ®	6	6	6	6
56	24005-12A	HANDLE	1	1	1	1
56A	24003-12A	HANDLE	1	1	1	1
58	54009-936	HANDLE BEZEL	4	4	4	4
59	10081-BK630	NAMEPLATE	2	2	2	2
60	10571-6	HEAT INDICATOR	2	2	2	2
65	20005-000	MATCH LIGHT - STICK	2	2	2	2
68	23272-111A	DOOR - BLACK	2	2	•	•
	23272-114A	DOOR - S.S	•	•	2	2
69	23272-131A	DOOR - BLACK	1	1	•	•
	23272-134A	DOOR - S.S	•	•	1	1

## PARTS LIST / LISTE DES PIECES

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>9972-82</u>	<u>9972-83</u>	<u>9973-42</u>	<u>9973-43</u>
70	21070-13	HANDLE BEZEL	6	6	6	6
71	21071-13	HANDLE - SMALL	3	3	3	3
78	21335-111	BRACKET - DOOR CATCH	1	1	1	1
78A	21333-921	BRACKET - DOOR CATCH	1	1	1	1
80	21109-901R	SIDE PANEL	3	3	3	3
82	25208-201	CABINET SHELF	1	1	1	1
83	21036-901	CABINET SHELF SUPPORT	1	1	1	1
85	21039-301	TANK BASE	1	1	1	1
88	21305-921R	PANEL - REAR	1	1	1	1
88A	25308-921R	PANEL - REAR	1	1	1	1
90	25098-931	BASE	1	1	1	1
91	25208-201R	CABINET SHELF	1	1	1	1
100	21039-911	CASTOR BRACKET	3	3	3	3
102	10892-23	CASTOR	3	3	3	3
102A	10892-285	LEVELING CASTOR	3	3	3	3
114	23101-113	SHELF ASSEMBLY - RIGHT	1	1	1	1
115	23101-153	SHELF ASSEMBLY - SIDEBURNER	1	1	1	1
116	23209-911	SHELF FACIA - RH	1	1	1	1
117	23209-931	SHELF FACIA - LH	1	1	1	1
118	23409-608A	SHELF HANDLE	2	2	2	2
119	Y-11981	CARRAIGE BOLT	4	4	4	4
123	Y-12117	LID STOPS - SIDEBURNER	2	2	2	2
124	23001-271	SHELF-SIDE BURNER	1	1	1	1
125	23000-254	COVER-SIDE BURNER	1	1	1	1
126	10390-R81D	SIDE BURNER	1	•	1	•
	10390-R81A	SIDE BURNER	•	1	•	1
128	23009-99	GRID	1	1	1	1
130	27905-354	BURNER ROTISSERIE	1	1	1	1
131	10693-095	REAR BURNER-ORIFICE	1	•	1	•
	10693-099	REAR BURNER-ORIFICE	•	1	•	1
133	S15271	HANDLE	1	1	1	1
134	S15270	BALANCER	1	1	1	1
135	S15299	WASHER	1	1	1	1
136	S15263	BUSHING	2	2	2	2
137	S15260	SPIT ROD	1	1	1	1
138	S15287	4 PRONG FORKS	2	2	2	2
139	57039-901	ROTISSERIE BRACKET	1	1	1	1
140	S21125	SCREW #8 X 1/2	6	6	6	6
141	Y-11559	SCREW 1/4-20 X 1	8	8	8	8
144	Y-12220	BUSHING	1	1	1	1
145	S21235	HINGE PIN	2	2	2	2
145A	10240-17	HINGE PIN	1	1	1	1
146	S21233	HITCH PIN CLIP	3	3	3	3
147	Y-11231	LID BUMPER	4	4	4	4
147A	SP11-25	LID BUMPER	4	4	4	4
148	10240-20	DOOR PIN	3	3	3	3
149	Y-11551	DOOR PIN	3	3	3	3
150	Y-12124	DOOR PIN CAP	3	3	3	3
152	Y-12222	MAGNET	3	3	3	3
153	Y-12223	SNAP IN MAGNET	3	3	3	3
154	Y-11560	SCREW 1/4-20 X 1-1/2	12	12	12	12
155	S21124	SCREW #8 X 1/2	24	24	24	24
156	Y-11793	NUT 1/4-20	18	18	18	18

**PARTS LIST / LISTE DES PIECES**

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>9972-82</u>	<u>9972-83</u>	<u>9973-42</u>	<u>9973-43</u>
157	Y-12835	SCREW #6-32 X 0.25	2	2	2	2
158	Y-12646	SCREW - SHOULDER #8 X 1/2	2	2	2	2
159	S21136	SCREW #8-32 X 3/8	16	16	16	16
160	Y-29304	SCREW #10-24 X 3/8	12	12	12	12
161	Y-12310	SCREW 1/4-20 X 3/4	4	4	4	4
162	S35095	SCREW #10-24 X 5/8	2	2	2	2
163	S35094	SCREW #10-24 X 5/8	2	2	2	2
169	S21061	WING NUT	2	2	2	2
171	S15246	MOTOR	1	1	1	1
172	S15508	REAR BURNER ELECTRODE	1	1	1	1
173	S21362	SPRING	1	1	1	1
174	Y-12871	SCREW M4 X 0.7	2	2	2	2
180	Y-12857	WASHER	6	6	6	6
181	25030-73	LIGHT SWITCH WIRE	1	1	1	1
181A	25070-95	LIGHT SWITCH BUTTON	1	1	1	1
184	25080-80	BATTERY PACK	1	1	1	1
186	Y-12865	BOLT 1/4-20 X 1/2	53	53	53	53
190	25020-84	WIRE - LED LIGHT	1	1	1	1
191	25020-84	WIRE - LED LIGHT	1	1	1	1

